




HEAT EXPERIENCE

**BATTERY HEATED VEST
USER MANUAL**

VEST OVERVIEW




Power button
Three heating levels

Heating Elements front
Placed over chest

Chest Pocket
Keep you phone warm during winter

Battery pocket
Strategically placed for good moveability



BEFORE USE

Congratulations on your new Heat Experience Heated Vest. Before you start using them there are some things you should know.

1

The battery should be fully charged before first use, or after a long period (2 months or more) of no use.

Charge the battery by connect it to the supplied charger. When the red light is lit, charging is ongoing.

Charging takes about 4 hours, When charging is complete, the red light turns off, and a green light turns on.

The heated vest has three different heating levels. We recommend that you get to know how the product work before you head out on longer lasting adventures.

QUICK TIPS!

How to get the most out of your vest!

EN

2

The Heat Experience Heated vest are primarily designed as a mid layer piece.

Worn with a moisture wicking base layer, such as a light wool sweater, and a wind/rainproof outerlayer will give you a very flexible and comfortable setup.

We recommend that you turn on the heat before you feel cold, as a preventative measure. If you first get very cold, the body requires a lot of energy to regain heat.

For best effect; Turn on high for a short time, and adjust down when you feel the heat, further on, adjust heat when needed.

USE

Getting started


3

Open the zipper on the battery pocket, placed on the inside of the vest, connect the battery to the cable before inserting it into the pocket. Close the pocket zipper.


Press and hold the button on the chest for ~3 seconds, until the light turns on. The glove is now heating up, and the red light should be blinking slowly.

This process takes about 5 minutes. you can press the button once more to go directly in to one of the modes, this will however reduce the "heat boost effect"

1. CHARGE BATTERY



2. CONNECT BATTERY



3. TURN ON (HOLD THE BUTTON)



USE AND CARE

some tips for optimal durability and comfort.

4

Remember to remove battery before washing, and follow the instructions carefully, to ensure maximum lifespan of your heated vest.

A spare battery is a good idea if you use your product for longer times, remember to keep the extra battery at a temperature as close to room temperature as possible. A cold battery will have a reduced output.

The product is designed to work in conditions from 10 degrees to -20 degrees (Celsius).



-20 to 10°C

HEATING LEVELS

Level	Temperature*	Indicator light	Duration*
I	45°C/113°F	Blue	9 hours
II	50°C/122°F	White	7 hours
III	55°C/131°F	Red	4,5 hours

EN

*The duration and given temperature will vary depending on ambient temperature and conditions.

CERTIFICATIONS



CAUTION

Keep out of high temperatures. The built-in polymer lithium battery may explode or be damaged if exposed of high temperatures or fire.

Do not charge unattended, use only original charger.

Battery may explode if disposed of in fire.

Do not crush or disassemble.

All components should be recycled in according to local laws and regulations.

Keep the heated gloves away from children.

Should not be used by users unable to feel changes in temperature.

CONTACT

Do you have any more questions, feel free to reach out;

e-mail: contact@heatx.no

EN

Address:

Heatexp AS

Østre Rosten 102b, C/O Beach Mountain

7075 Tiller

NORWAY

Read more about Heat Experience, discover new products, and get inspired on our webpage www.heatexperience.eu

Follow us on social media:

facebook.com/theheatexperience

Instagram: Heat Experience

We hope you enjoy your product.
Kind regards, The Heat Experience Team.

